


FINISHING DETAILS

CONNECTION TO WALLS AND PLINTHS

Solution for connecting horizontal surfaces to vertical surfaces.


4	After the curing time, one of the systems, as described in the folder, can be applied to the horizontal surface.
3	2 or 3 layers POLYAC® BDM M manually applied, using a brush or roller.
2	Coved skirting POLYAC® BDM M using POLYAC® Thixogène.
1	POLYAC® Primer – depending on the substrate.
S	Substrate



CONNECTION TO CHANNEL DRAINS

Solution for connecting the aforementioned systems to integrated channel drains.

3	After the curing time, one of the systems as described in the folder can be applied to the horizontal surface.
2	Primer adjusted to the type of substrate.
1	The integrated channel drain must first be installed and anchored in the concrete surface, using POLYAC® M.
S	Substrate



CONNECTION TO TRAFFICABLE EXPANSION JOINT PROFILES

Solution for connecting the aforementioned systems to integrated expansion joints profiles.

3	After the curing time, one of the systems, as described in the folder, can be applied to the horizontal surface.
2	Primer adjusted to the type of substrate.
1	The expansion joint profiles must be installed and anchored in the concrete. Use POLYAC® M to level out with the rest of the surface.
S	Substrate

